# **JVC**

Dear Customer,

Thank you for purchasing this digital video camera. Before use, please read the safety information and precautions contained in the pages 3 – 4 and 9 to ensure safe use of this product.

**ENGLISH** 

### **DIGITAL VIDEO CAMERA**

**GR-D250** 

Please visit our Homepage on the World Wide Web for Digital Video Camera:

http://www.jvc.co.jp/english/cyber/

For Accessories:

http://www.jvc.co.jp/english/accessory/

GETTING STARTED

VIDEO RECORDING & PLAYBACK

17

6

ADVANCED FEATURES 22

REFERENCES 38

TERMS

47



#### For Customer Use:

Enter below the Model No. and Serial No. which is located on the bottom of the camcorder. Retain this information for future reference. **Model No.** 

Serial No.

To deactivate the demonstration, set "DEMO MODE" to "OFF". (☐ pg. 22, 25)


INSTRUCTIONS



### **Major Features of this Camcorder**

### Wipe/Fader Effects

You can use the Wipe/Fader Effects to make pro-style scene transitions. ( pg. 33)



### **Program AE with Special Effects**


For example, "SPORTS" mode allows fast-moving images to be captured one frame at a time, for vivid, stable slow-motion. ( pp. 34)



### **Backlight Compensation**

Simply pressing the **BACK LIGHT** button brightens the image darkened by backlight. ( $\wp$  pg. 31)

 You can also select a spot metering area so that more precise exposure compensation is available. ( pg. 31, Spot Exposure Control)



### **Data Battery**

You can check the battery status by simply pressing the **DATA** button. (Fig. 12)

BATTERY CONDITION		
LEVEL	MAX TIME	
100%	LCD 60min	
0	FINDER 80min	

### **SAFETY PRECAUTIONS**



CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

# WARNING: TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS UNIT TO RAIN OR MOISTURE.

#### **CAUTIONS:**

- This camcorder is designed to be used with NTSC-type color television signals. It cannot be used for playback with a television of a different standard. However, live recording and LCD monitor/viewfinder playback are possible anywhere.
- This product includes patented and other proprietary technology and will operate only with JVC Data Battery. Use the JVC BN-VF707U/VF714U/VF733U battery packs and, to recharge them or to supply power to the camcorder from an AC outlet, use the provided multi-voltage AC Adapter. (An appropriate conversion adapter may be necessary to accommodate different designs of AC outlets in different countries.)

#### Caution on Replaceable lithium battery

The battery used in this device may present a fire or chemical burn hazard if mistreated.

Do not recharge, disassemble, heat above 100°C (212°F) or incinerate.

Replace battery with Panasonic (Matsushita Electric), Sanyo, Sony or Maxell CR2025.

Danger of explosion or Risk of fire if the battery is incorrectly replaced.

- Dispose of used battery promptly.
- Keep away from children.
- Do not disassemble and do not dispose of in fire.

#### NOTES:

- The rating plate (serial number plate) and safety caution are on the bottom and/or the back of the main unit.
- The rating information and safety caution of the AC Adapter are on its upper and lower sides.

This product has a fluorescent lamp that contains a small amount of mercury. Disposal of these materials may be regulated in your community due to environmental considerations.

For disposal or recycling information please contact your local authorities, or the Electronics Industries Alliance:

<a href="http://www.eiae.org">http://www.eiae.org</a>

When the equipment is installed in a cabinet or on a shelf, make sure that it has sufficient space on all sides to allow for ventilation (10 cm (3–15/16") or more on both sides, on top and at the rear).

Do not block the ventilation holes.

(If the ventilation holes are blocked by a newspaper, or cloth etc. the heat may not be able to get out.)

No naked flame sources, such as lighted candles, should be placed on the apparatus.

When discarding batteries, environmental problems must be considered and the local rules or laws governing the disposal of these batteries must be followed strictly.

The apparatus shall not be exposed to dripping or splashing.

Do not use this equipment in a bathroom or places with water.

Also do not place any containers filled with water or liquids (such as cosmetics or medicines, flower vases, potted plants, cups etc.) on top of this unit. (If water or liquid is allowed to enter this equipment, fire or electric shock may be caused.)

Do not point the lens or the viewfinder directly into the sun. This can cause eye injuries, as well as lead to the malfunctioning of internal circuitry. There is also a risk of fire or electric shock.

#### CAUTION!

The following notes concern possible physical damage to the camcorder and to the user.

When carrying, be sure to always securely attach and use the provided strap. Carrying or holding the camcorder by the viewfinder and/or the LCD monitor can result in dropping the unit, or in a malfunction.

Take care not to get your finger caught in the cassette holder cover. Do not let children operate the camcorder, as they are particularly susceptible to this type of injury.

Do not use a tripod on unsteady or unlevel surfaces. It could tip over, causing serious damage to the camcorder.

#### CAUTION!

Connecting cables (Audio/Video, S-Video, etc.) to the camcorder and leaving it on top of the TV is not recommended, as tripping on the cables will cause the camcorder to fall, resulting in damage.

### IMPORTANT SAFETY INSTRUCTIONS


- 1. Read these instructions.
- 2. Keep these instructions.
- Heed all warnings.
- 4. Follow all instructions.
- Do not use this apparatus near water.
  - 6. Clean only with dry cloth.
  - Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
  - Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
  - Only use attachments/accessories specified by the manufacturer.
  - 10. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/



- apparatus combination to avoid injury from tipover.
- 11. Unplug this apparatus during lightning storms or when unused for long periods of time.
- 12. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

GETTING STARTED	6	ADVANCED FEATURES	22
Index	6	MENUS FOR DETAILED ADJUSTMENT	22
Provided Accessories	. 10	Changing The Menu Settings	22
Power	. 11	Recording Menus	
Operation Mode	. 13	Playback Menus	
Language Settings	. 14	FEATURES FOR RECORDING	
Date/Time Settings	. 14	5-Second Recording	
Grip Adjustment	. 14	Night-Alive	
Viewfinder Adjustment	. 15	Snapshot (For Video Recording)	
Brightness Adjustment Of The Display	. 15	Manual Focus	
Tripod Mounting		Exposure Control	
Loading/Unloading A Cassette	. 16	Iris Lock	
\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\		Backlight Compensation	
VIDEO RECORDING & PLAYBACK	17	Spot Exposure Control	
VIDEO DECORDINO		White Balance Adjustment	
VIDEO RECORDING		Manual White Balance Adjustment	32
Basic Recording	. 17	Wipe Or Fader Effects	33
Tape Remaining Time	. 17	Program AE With Special Effects	34
LCD Monitor And Viewfinder		EDITING	
Zooming		Dubbing To A VCR	
Journalistic Shooting		Dubbing To Or From A Video Unit Equipped	
Time Code		A DV Connector (Digital Dubbing)	
Quick Review		Connection To A Personal Computer	
Recording From The Middle Of A Tape		р	
VIDEO PLAYBACK		REFERENCES	38
Normal Playback			
Still Playback		TROUBLESHOOTING	38
Shuttle Search		USER MAINTENANCE	42
Blank Search		CAUTIONS	43
Connections To A TV Or VCR	. 21	SPECIFICATIONS	
		TERMS	47

# Index



### **Controls**

- ① Stop Button [■] (☞ pg. 20) Backlight Compensation Button [BACK LIGHT] (☞ pg. 31)
- ② Play/Pause Button [►/II] (□ pg. 20)
  Manual Focus Button [FOCUS] (□ pg. 29)
- ③ Rewind Button [◄◄] (☞ pg. 20) Menu select Button [–] (☞ pg. 14) Quick Review Button [ᢏ] (☞ pg. 19)
- ④ Fast-Forward Button [►►] (□ pg. 20) Menu select Button [+] (□ pg. 14) Night Button [NIGHT] (□ pg. 28)
- ⑤ Menu Button [MENU] ( pg. 22)

  Data Battery Button [DATA] ( pg. 12)
- 6 Dioptre Adjustment Control ( pg. 15)
- 7 Snapshot Button [SNAPSHOT] (F pg. 29)
- ® Power Zoom Lever [T/W] (\$\top pg. 18\$) Speaker Volume Control [VOL. +, -] (\$\top pg. 20\$)
- Battery Release Button [PUSH BATT.]
   pg. 11)
- (1) Recording Start/Stop Button (127 pg. 17)
- ① Power Switch [A, M, PLAY, OFF] (F pg. 13)
- 12 Lock Button (F pg. 13)
- ③ Cassette Open/Eject Switch [OPEN/EJECT] (□ pg. 16)

### **Connectors**

The connectors are located beneath the covers.

- Audio/Video Output Connector [AV] (pp. 21, 35)
- ⑤ DC Input Connector [DC] (☐ pg. 11)
- Digital Video Connector [DV IN/OUT] (i.Link\*) (☞ pg. 36, 37)
- i.Link refers to the IEEE1394-1995 industry specification and extensions thereof. The i logo is used for products compliant with the i.Link standard.

### Indicators


17 POWER/CHARGE Lamp (12 pg. 11, 17)

### Other Parts

- 18 Monitor Latch ( pg. 18)
- 19 LCD Monitor (127 pg. 18, 19)
- 20 Viewfinder (pg. 15)
- 21 Battery Pack Mount (pp. 12)
- 22 Shoulder Strap Eyelet ( pg. 11)
- 23 Speaker (127 pg. 20)
- 24 Grip Strap (F pg. 14)
- 25 Lens
- Camera Sensor (Be careful not to cover this area, a sensor necessary for shooting is built-in here.)
- 27 Stereo Microphone
- 28 Stud Hole (127 pg. 15)
- ☑ Tripod Mounting Socket (☞ pg. 15)
- Cassette Holder Cover ( pg. 16)

# LCD Monitor/Viewfinder Indications


### **During Video Recording**



- ① Operation Mode (F pg. 13)
- ② 
   Night-Alive Indicator (□ pg. 28)
   A: Gain Up Mode (□ pg. 23)
- ③ White Balance Indicator (F pg. 32)
- ④ : Spot Exposure Control Indicator (☐ pg. 31)
  - Backlight Compensation Indicator
     □ pg. 31)
  - ±: Exposure Adjustment Indicator ( pg. 30)
- ⑤ Selected Program AE With Special Effects Indicator (☞ pg. 34)
- 6 Iris Lock Indicator (F pg. 30)
- SOUND 12BIT/16BIT: Sound Mode Indicator (pp g. 23) (Appears for approx. 5 seconds after turning on the camcorder.)
- ® Digital Image Stabilizer ("DIS") (☐ pg. 24)
- Approximate Zoom Ratio ( pg. 18)
- 10 Zoom Indicator (pg. 18)
- ① Selected Wipe/Fader Effect Indicator (F) pg. 33)
- ① Tape Running Indicator (Fig. 17) (Rotates while tape is running.)
- Selected Wide Mode Indicator ( pg. 24)
- (4) Recording Speed Mode (SP/LP) (F pg. 23)
- (5) Tape Remaining Time (127 pg. 17)
- ® REC: (Appears during recording.) (ppg. 17) PAUSE: (Appears during Record-Standby mode.) (ppg. 17)
  - **PHOTO**: (Appears when taking Snapshot.) (pp pg. 29)
- 5S/Anim.: Displays the 5-Second Recording mode or Animation recording mode.
   ( pg. 24)
- <sup>®</sup> Wind Cut Indicator (□ pg. 24)
- Battery Remaining Power Indicator
   ( pg. 40)
- ② Date/Time ( pg. 14)

- Brightness Control Indicator (LCD monitor/ Viewfinder) (Ppg. 15)
- ② Manual Focus Adjustment Indicator ( pg. 29)
- 23 Time Code (127 pg. 26, 27)

### **During Video Playback**



- 1 Sound Mode Indicator (F pg. 26)
- 2 Blank Search Indicator (pg. 20)
- ③ Tape Speed (□ pg. 23)
- ④ ►: Playback
  - ►►: Fast-Forward/Shuttle Search
  - : Rewind/Shuttle Search
  - II: Pause
  - II ►: Forward Frame-By-Frame Playback/ Slow-Motion
  - II: Reverse Frame-By-Frame Playback/ Slow-Motion
- ⑤ Battery Remaining Power Indicator ( pg. 40)
- ⑥ Date/Time (pg. 26, 27)
- ⑦ VOLUME: Volume Level Indicator (☞ pg. 20) BRIGHT: Brightness Control Indicator (LCD monitor/Viewfinder) (☞ pg. 15)
- ® Time Code (□ pg. 26, 27)

### **Before Using This Camcorder**

# Make sure you only use cassettes with the Mini DV mark Mini DV.

This camcorder is designed exclusively for the digital video cassette. Only cassettes marked "Mri IX" can be used with this unit.

Remember that this camcorder is not compatible with other digital video formats.

# Remember that this camcorder is intended for private consumer use only.

Any commercial use without proper permission is prohibited. (Even if you record an event such as a show, performance or exhibition for personal enjoyment, it is strongly recommended that you obtain permission beforehand.)

### Before recording important video, be sure to make a trial recording.

Play back your trial recording to make sure the video and audio have been recorded properly.

### We recommend cleaning your video heads before use.

If you haven't used your camcorder for a while, the heads may be dirty. We recommend periodically cleaning the video heads with a cleaning cassette (optional).

### Be sure to store your cassette tapes and camcorder in the proper environment.

Video heads can become dirty more easily if your cassette tapes and camcorder are stored in a dusty area. Cassette tapes should be removed from the camcorder and stored in cassette cases. Store the camcorder in a bad or other container.

# Use SP (Standard) mode for important video recordings.

LP (Long Play) mode lets you record 50% more video than SP (Standard) mode, but you may experience mosaic-like noise during playback depending on the tape characteristics and the usage environment.


So, for important recordings, we recommend using SP mode.

### It is recommended that you use JVC brand cassette tapes.

Your camcorder is compatible with all brands of commercially available cassette tapes complying with the MiniDV standard, but JVC brand cassette tapes are designed and optimized to maximize the performance of your camcorder.

Also read "CAUTIONS" on pages 43 - 45.

### **Provided Accessories**



- ① AC Adapter AP-V16U or AP-V14U
- ② Battery Pack BN-VF707U
- Audio/Video Cable (ø3.5 mini-plug to RCA plug)
- ④ Shoulder Strap (□ pg. 11 for attachment)
- Lens Cap (see the right column for attachment)

#### NOTES:

- In order to maintain optimum performance of the camcorder, provided cables may be equipped with one or more core filter. If a cable has only one core filter, the end that is closest to the filter should be connected to the camcorder.
- Make sure to use the provided cables for connections. Do not use any other cables.

### How To Attach The Lens Cap


To protect the lens, attach the provided lens cap to the camcorder as shown in the illustration

### NOTE:

To confirm the lens cap is on correctly make sure the cap is flush to the camcorder.




shooting.



### How To Attach The Shoulder Strap

Follow the illustration.


- Thread the strap through the eyelet.
- 2 Fold it back and thread it through the strap guide and the buckle.
- To adjust the length of the strap, loosen and then tighten the strap in the buckle.
- 3 Slide the strap guide fully towards the eyelet.



### **Power**

This camcorder's 2-way power supply system lets you choose the most appropriate source of power. Do not use provided power supply units with other equipment.

### **Charging The Battery Pack**



- I Set the Power Switch to "OFF".
- 2 With the arrow on the battery pack pointing downward, push the battery pack slightly against the battery pack mount 1.
- 3 Slide down the battery pack until it locks in place 2.
- **4** Connect the AC Adapter to the camcorder.
- 5 Plug the AC Adapter into an AC outlet. The POWER/CHARGE lamp on the camcorder blinks to indicate charging has started.
- **6** When the POWER/CHARGE lamp goes out, charging is finished. Unplug the AC Adapter from the AC outlet. Disconnect the AC Adapter from the camcorder.

### To detach the battery pack

Slide the battery pack upward while pressing **PUSH BATT.** to detach it.

Battery pack	Charging time
BN-VF707U*	Approx. 1 hr. 30 min.
BN-VF714U	Approx. 2 hr. 40 min.
BN-VF733U	Approx. 5 hr. 40 min.

Provided

### **NOTES:**

- This product includes patented and other proprietary technology and will operate only with JVC Data Battery. Use the JVC BN-VF707U/VF714U/VF733U battery packs. Using generic non-JVC batteries can cause damage to the internal charging circuitry.
- If the protective cap is attached to the battery pack, remove it first.
- During charging, the camcorder cannot be operated.
- Charging is not possible if the wrong type of battery is used.
- When charging the battery pack for the first time or after a long storage period, the POWER/ CHARGE lamp may not light. In this case, remove the battery pack from the camcorder, then try charging again.
- If the battery operation time remains extremely short even after having been fully charged, the battery is worn out and needs to be replaced.
   Please purchase a new one.
- Since the AC Adapter processes electricity internally, it becomes warm during use. Be sure to use it only in well-ventilated areas.
- Using the optional AA-VF7 Battery Charger, you can charge the BN-VF707U/VF714U/VF733U battery pack without the camcorder.
- After 5 minutes has elapsed in Record-Standby mode with the cassette inserted, the camcorder will automatically turn off its power supplied from the AC adapter. In this case, the battery charge starts if the battery is attached to the camcorder.

### **Using The Battery Pack**

Perform steps **2** – **3** in "Charging The Battery Pack".

### Maximum continuous recording time

Battery pack	LCD monitor on	Viewfinder on
BN-VF707U*	1 hr. 5 min.	1 hr. 25 min.
BN-VF714U	2 hr. 20 min.	3 hr.
BN-VF733U	5 hr. 25 min.	7 hr. 5 min.

Provided

### **NOTES:**

- Recording time is reduced significantly under the following conditions:
  - Zoom or Record-Standby mode is engaged repeatedly.
  - The LCD monitor is used repeatedly.
  - The playback mode is engaged repeatedly.
- Before extended use, it is recommended that you prepare enough battery packs to cover 3 times the planned shooting time.

#### ATTENTION:

Before detaching the power source, make sure that the camcorder's power is turned off. Failure to do so can result in a camcorder malfunction.

### **Data Battery System**

You can check the remaining battery power and the recordable time.

- 1) Make sure the battery is attached and the Power Switch is set to "OFF".
- 2) Open the LCD monitor fully.
- Press DATA, and the battery status screen appears.
- It can be displayed on the viewfinder when the LCD monitor is closed.
- It is displayed for approx. 5 seconds if the button is pressed and released quickly, and for approx. 15 seconds if the button is pressed and hold for several seconds.
- If "COMMUNICATION ERROR" appears instead of the battery status even though you tried to press DATA several times, there may be a problem with your battery. In such a case, consult your nearest JVC dealer.

### **Using AC Power**

Perform step 4 in "Charging The Battery Pack".

#### NOTE:

The provided AC Adapter features automatic voltage selection in the AC range from 110 V to 240 V

### **About Batteries**


**DANGER!** Do not attempt to take the batteries apart, or expose them to flame or excessive heat, as it may cause a fire or explosion. WARNING! Do not allow the battery or its terminals to come in contact with metals, as this can result in a short circuit and possibly start a fire.

### To resume the original function of the accurate battery power indication

If the battery power indication differs from the actual operating time, fully charge the battery, and then run it down. However this function may not turn back if the battery was used for a long period of time under extremely high/low temperature condition or charged too many times.

### **Operation Mode**

To turn on the camcorder, set the Power Switch to any operation mode except "OFF" while pressing down the Lock Button located on the switch.



Choose the appropriate operation mode according to your preference using the Power Switch.

### **Power Switch Position**

### 

Allows you to record using NO special effects or manual adjustments. Suitable for standard recording.

The "A" indicator appears on the display.

### M (Manual Recording):

Allows you to set various recording functions using the Menus. (pg. 22)

If you want more creative capabilities than Full Auto Recording, try this mode.

#### OFF.

Allows you to switch off the camcorder.

- Allows you to play back a recording on the
- Allows you to set various playback functions using the Menus. (F pg. 22)

### **Power-Linked Operation**

When the Power Switch is set to "A" or "M", you can also turn on/off the camcorder by opening/ closing the LCD monitor or pulling out/pushing in the viewfinder.

### INFORMATION:

The following explanations in this manual supposes the use of LCD monitor in your operation. If you want to use the viewfinder, close the LCD monitor and pull out the viewfinder fully.

### Language Settings

The language on the display can be changed. (F pg. 22, 26, 27)

- 1 Set the Power Switch to "M" while pressing down the Lock Button located on the switch.
- 2 Open the LCD monitor fully. ( pg. 18)
- 3 Press MENU. The Menu Screen appears.
- 4 Press + or to select "2", and press MENU. The CAMERA DISPLAY Menu appears.
- **5** Press + or to select "LANGUAGE", and press **MENU**.
- **6** Press + or to select the desired language, and press **MENU**.
- **7** Press + or to select "URETURN", and press **MENU** twice. The Menu Screen closes.





### Date/Time Settings


The date/time is recorded onto the tape at all times, but its display can be turned on or off during playback. ( pp. 22, 27)

- 1 Perform steps 1 4 in "Language Settings" on the left column
- **2** Press + or to select "CLOCK ADJ.", and press **MENU**. The parameter for "Month" is highlighted.
- **3** Press + or to input the month, and press **MENU**. Repeat to input the day, year, hour and minute.
- 4 Press + or to select
  "URETURN", and press
  MENU twice. The Menu Screen closes.



### Grip Adjustment


- Adjust the velcro strip.
- **2** Pass your right hand through the loop and grasp the grip.
- **3** Adjust your thumb and fingers through the grip to easily operate the Recording Start/Stop Button, Power Switch and Power Zoom Lever. Be





### Viewfinder Adjustment

- Set the Power Switch to "A" or "M" while pressing down the Lock Button located on the switch.
- 2 Make sure the LCD monitor is closed and locked. Pull out the viewfinder fully and adjust it manually for best viewability.
- 3 Turn the Dioptre Adjustment Control until the indications in the viewfinder are clearly focused. Example:



**Dioptre Adjustment Control** 

### CAUTION:

When retracting the viewfinder, take care not to pinch your fingers.


### **Brightness Adjustment Of The** Display


- Set the Power Switch to "M" or "PLAY" while pressing down the Lock Button located on the switch.
- $oldsymbol{2}$  Open the LCD monitor fully. (🖙 pg. 18)
- To adjust the brightness of the viewfinder, pull out the viewfinder fully and set "PRIORITY" to "FINDER" (cr pg. 22, 25).
- 3 Press MENU. The Menu Screen appears.
- 4 Press + or to select "O", and press MENU. The CAMERA DISPLAY or VIDEO DISPLAY Menu appears.
- 5 Press + or to select "BRIGHT", and press MENU. The Menu Screen closes and the brightness control indicator appears.
- **6** Press + or until the appropriate brightness is reached.
- **7** Press **MENU** to clear the brightness control indicator from the display.

### **Tripod Mounting**

To attach the camcorder to a tripod, align the direction stud and screw to the mounting socket and stud hole on the camcorder. Then tighten the screw clockwise.


 Some tripods are not equipped with studs.





### Loading/Unloading A Cassette

The camcorder needs to be powered up to load or eject a cassette.



1 Slide and hold **OPEN/EJECT** in the direction of the arrow, then pull the cassette holder cover open until it locks. The cassette holder opens automatically.

- Do not touch internal components.
- 2 Insert or remove a tape and press "PUSH HERE" to close the cassette holder.
- Be sure to press only the section labelled "PUSH HERE" to close the cassette holder; touching other parts may cause your finger to get caught in the cassette holder, resulting in injury or product damage.
- Once the cassette holder is closed, it recedes automatically. Wait until it recedes completely before closing the cassette holder cover.
- When the battery pack's charge is low, you may not be able to close the cassette holder cover. Do not apply force. Replace the battery pack with a fully charged one or use AC power before continuing.
- **3** Close the cassette holder cover firmly until it locks into place.

### To protect valuable recordings

Slide the erase protection tab on the back of the tape in the direction of "SAVE". This prevents the tape from being recorded over. To record on this tape, slide the tab back to "REC" before loading it.

- If you wait a few seconds and the cassette holder does not open, close the cassette holder cover and try again. If the cassette holder still does not open, turn the camcorder off then on again.
- If the tape does not load properly, open the cassette holder cover fully and remove the cassette. A few minutes later, insert it again.
- When the camcorder is suddenly moved from a cold place to a warm environment, wait a short time before opening the cassette holder cover.

### **Basic Recording**

#### NOTE:

Before continuing, perform the procedures listed

- Power (□ pg. 11)
- Loading A Cassette (pg. 16)



Power Zoom Lever

Power Switch

Lock Button

POWER/CHARGE Lamp

Recording Start/Stop Button

Remove the lens cap. ( pg. 10)

2 Open the LCD monitor fully.

3 Set the Power Switch to "A" or "M" while pressing down the Lock Button located on the switch.

- The POWER/CHARGE lamp lights and the camcorder enters the Record-Standby mode. "PAUSE" is displayed.
- To record in LP (Long Play) mode, pg. 23.

4 To start recording, press the Recording Start/ Stop Button. "SREC" appears on the display while recording is in progress.

5 To stop recording, press the Recording Start/ Stop Button again. The camcorder re-enters the Record-Standby mode.

### Approximate recording time

Tape	Recording mode	
Tape	SP	LP
30 min.	30 min.	45 min.
60 min.	60 min.	90 min.
80 min.	80 min.	120 min.

### **NOTES:**

- If the Record-Standby mode continues for 5 minutes, the camcorder's power shuts off automatically. To turn the camcorder on again, push back and pull out the viewfinder again or close and re-open the LCD monitor.
- When a blank portion is left between recorded scenes on the tape, the time code is interrupted and errors may occur when editing the tape. To avoid this, refer to "Recording From The Middle Of A Tape" (pg. 19).
- To turn the beep sounds off, pg. 22, 25.

### **Tape Remaining Time**

Approximate tape remaining time appears on the display. "-h-m" means the camcorder is calculating the remaining time. When the



remaining time reaches 2 minutes, the indication starts blinking.

• The time required to calculate and display the remaining tape length, and the accuracy of the calculation, may vary according to the type of tape


### **LCD Monitor And Viewfinder**

### While using the LCD monitor:

Make sure the viewfinder is pushed back in. Pull on the end (a) of the LCD monitor and open the LCD monitor fully. It can rotate 270° (90° downward, 180° upward).

### While using the viewfinder:

Make sure the LCD monitor is closed and locked. Pull out the viewfinder fully.



#### **NOTES:**

- The image will not appear simultaneously on the LCD monitor and the viewfinder. When the viewfinder is pulled out while the LCD monitor is opened, you can select which one to use. Set "PRIORITY" to the desired mode in SYSTEM Menu. (pp. 22, 25)
- Colored bright spots may appear all over the LCD monitor or the viewfinder. However, this is not a malfunction. ( pp. 39)

### Zooming

Produces the zoom in/out effect, or an instantaneous change in image magnification.


#### Zoom In

Slide the Power Zoom Lever towards "T".

#### Zoom Out

Slide the Power Zoom Lever towards "W".

 The further you slide the Power Zoom Lever, the quicker the zoom action.



- Focusing may become unstable during Zooming. In this case, set the zoom while in Record-Standby, lock the focus by using the manual focus (zp pg. 29), then zoom in or out in Record mode.
- Zooming is possible to a maximum of 800X, or it can be switched to 25X magnification using the optical zoom. ( pp. 23)
- Zoom magnification of over 25X is done through Digital image processing, and is therefore called Digital Zoom.
- During Digital zoom, the quality of image may suffer.
- Macro shooting (as close as approx. 5 cm (2") to the subject) is possible when the Power Zoom Lever is set all the way to "W". Also see "TELE MACRO" in MANUAL Menu on page 24.
- When shooting a subject close to the lens, zoom out first. If zoomed-in in the auto focus mode, the camcorder may automatically zoom out depending on the distance between the camcorder and the subject. This will not occur when "TELE MACRO" is set to "ON". (
  pg. 24)

### Journalistic Shooting

In some situations. different shooting angles may provide more dramatic results. Hold the camcorder in the desired position and tilt the LCD monitor in the most convenient direction. It can rotate 270° (90° downward, 180° upward).



### Time Code

During recording, a time code is recorded on the tape. This code is to confirm the location of the recorded scene on the tape during playback.

### Display



Frames are not displayed during recording.

If recording starts from a blank portion, the time code begins counting from "00:00:00" (minute:second:frame). If recording starts from the end of a previously recorded scene, the time code continues from the last time code number. If during recording a blank portion is left partway through the tape, the time code is interrupted. When recording is resumed, the time code starts counting up again from "00:00:00". This means the camcorder may record the same time codes as those existing in a previously recorded scene. To prevent this, perform Recording From The Middle Of A Tape (pg. 19) in the following cases:

- When shooting again after playing back a recorded tape.
- When power shuts off during shooting.
- When a tape is removed and re-inserted during shooting.
- When shooting using a partially recorded tape.
- When shooting on a blank portion located partway through the tape.
- When shooting again after shooting a scene then opening/closing the cassette holder cover.

#### NOTES:

- The time code cannot be reset.
- During fast-forwarding and rewinding, the time code indication does not move smoothly.
- The time code is displayed only when "TIME CODE" is set to "ON". (pg. 26)

### **Quick Review**


Enables to check the end of the last recording.

- 1) Press during the Recording-Standby mode.
- 2) Tape is rewound for about several seconds and played back automatically, then pauses in the Recording-Standby mode for the next shot.
- Distortion may occur at start of playback. This is normal.

### Recording From The Middle Of A Tape

- 1) Play back a tape or use Blank Search (pg. 20) to find the spot at which you want to start recording, then engage the Still Playback mode. (F pg. 20)
- 2) Set the Power Switch to "A" or "M" while pressing down the Lock Button located on the switch, then start recording.

# Normal Playback



- Load a cassette. (r pg. 16)
- **2** Set the Power Switch to "PLAY" while pressing down the Lock Button located on the switch.
- 3 To start playback, press ►/II.
- **4** To stop playback, press ■.

### To control the speaker volume

Slide the Power Zoom Lever (**VOL.** +/-) towards "+" to turn up the volume, or towards "-" to turn down the volume.

#### **NOTES:**

- The playback picture can be viewed in the LCD monitor, viewfinder or on a connected TV.
   pg. 21)
- If Stop mode continues for 5 minutes when power is supplied from a battery, the camcorder shuts off automatically. To turn on again, set the Power Switch to "OFF", then to "PLAY".
- When a cable is connected to the AV connector, the sound is not heard from the speaker.

### Still Playback

Pauses during video playback.

- 1) Press ►/II during playback.
- 2) To resume normal playback, press ►/II again.
- If still playback continues for more than about 3 minutes, the camcorder's Stop mode is automatically engaged.

### **Shuttle Search**

Allows high-speed search in either direction during video playback.

- 1) During playback, press ►► for forward search, or ◀◀ for reverse search.
- 2) To resume normal playback, press ►/II.

- During playback, press and hold ►► or ◄◄. The search continues as long as you hold the button. Once you release the button, normal playback resumes.
- A slight mosaic effect appears on the display during Shuttle Search. This is not a malfunction.

#### ATTENTION:

During Shuttle Search, parts of the picture may not be clearly visible, particularly on the left side of the screen.




### Blank Search

Helps you find where you should start recording in the middle of a tape to avoid time code interruption. ( pp. 19)

- Load a cassette. (pg. 16)
- 2 Set the Power Switch to "PLAY" while pressing down the Lock Button located on the switch.
- **3** Press **MENU**. The Menu Screen appears.
- 4 Press MENU to select ". The VIDEO Menu appears.
- **5** Press + or to select "BLANK SRCH", and press **MENU**. The Sub Menu appears.
- **6** Press + or to select "EXECUTE", and press **MENU**.
- The "BLANK SEARCH" indication appears and the camcorder automatically starts reverse or forward search, then stops at the spot which is about 3 seconds of tape before the beginning of the detected blank portion.
- To cancel Blank Search, press ■.

- Before starting Blank Search, if the current position is at a blank portion, the camcorder searches in the reverse direction. If the current position is at a recorded portion, the camcorder searches in the forward direction.
- If the beginning or end of the tape is reached during Blank Search, the camcorder stops automatically.
- A blank portion which is shorter than 5 seconds of tape may not be detected.
- The detected blank portion may be located between recorded scenes. Before you start recording, make sure there is no recorded scene after the blank portion.

### Connections To A TV Or VCR



- 1 Yellow to VIDEO IN (Connect when your TV/ VCR has only A/V input connectors.)
- Red to AUDIO R IN\*
- White to AUDIO L IN\*
- \* Not required for watching still images only.

- Make sure all units are turned off.
- 2 Connect the camcorder to a TV or VCR as shown in the illustration.

If using a VCR, go to step 3. If not, go to step 4.

- **3** Connect the VCR output to the TV input, referring to your VCR's instruction manual.
- 4 Turn on the camcorder, the VCR and the TV.
- 5 Set the VCR to its AUX input mode, and set the TV to its VIDEO mode.
- **6** Start playback on the camcorder. ( pg. 20)

### To choose whether or not the following displays appear on the connected TV


- Date/Time Set "DATE/TIME" to "AUTO". "ON" or "OFF". (c) pg. 22, 27)
- Time Code Set "TIME CODE" to "ON" or "OFF". (c) pg. 22, 27)
- Indications other than date/time and time code Set "ON SCREEN" to "OFF", "LCD" or "LCD/TV". (c) pg. 22, 27)

- It is recommended to use the AC Adapter as the power supply instead of the battery pack. (car pq. 13)
- To monitor the picture and sound from the camcorder without inserting a tape, set the camcorder's Power Switch to "A" or "M", then set your TV to the appropriate input mode.
- Make sure you adjust the TV sound volume to its minimum level to avoid a sudden burst of sound when the camcorder is turned on.

# Changing The Menu Settings

This camcorder is equipped with an easy-to-use, on-screen menu system that simplifies many of the more detailed camcorder settings.

 $(\mathbb{F} pq. 23 - 27)$ 



### I For Video Recording Menus:

Set the Power Switch to "M" while pressing down the Lock Button located on the switch.

### For Video Playback Menus:

Set the Power Switch to "PLAY" while pressing down the Lock Button located on the switch.

- 2 Open the LCD monitor fully. ( pg. 18)
- **3** Press **MENU**. The Menu Screen appears.
- 4 Press + or to select the desired function, and press MENU. The selected function menu appears.

#### Screen for Video Recording Menu



### Screen for Video Playback Menu



5 Setting procedure hereafter depends on the selected function.

### Menus without Sub Menus

### IS WIPE/FADER (cr pg. 33)

PROGRAM AE (car pa. 34)

EXPOSURE (pg. 30)

W. BALANCE (r pg. 32)

- Press + or to select the desired parameter.
- AE Menu
- 2) Press MENU. Selection is complete. The Menu Screen returns.
- Repeat the procedure if you wish to set other function menus.
- Press MENU. The Menu Screen closes.

### Menus with Sub Menus

MANUAL

(c pg. 24)

3 SYSTEM (1 pg. 25) CAMERA DISPLAY

(r pg. 26)

**™** VIDEO (⊯ pg. 26) VIDEO DISPLAY

(car pq. 27)

Menu

- 1) Press + or to select the desired function. and press MENU. The
- Sub Menu appears. Example: A CAMERA
- Press + or to select the desired parameter.
- Press MENU. Selection is complete.
- Repeat the procedure if vou wish to set other function menus.
- Press MENU. The Menu Screen returns.
- Repeat the procedure if you wish to set other function menus.
- Press MENU. The Menu Screen closes.

### Selected parameter PROGRAM AE SPORTS

Selected menu icon

blinks.



### Selected menu icon blinks.









### **Recording Menus**

### **CAMERA**

The "A CAMERA" settings are effective when the Power Switch is set to both "A" and "M". However, the menu settings can be changed only when the Power Switch is set to "M". [] = Factory-preset

### **REC MODE**

[SP]: To record in the SP (Standard Play) mode LP: Long Play—more economical, providing 1.5 times the recording time.

### **NOTES:**

- If the recording mode is switched, the playback picture will be blurred at the switching point.
- It is recommended that tapes recorded in the LP mode on this camcorder be played back on this
- During playback of a tape recorded on another camcorder, blocks of noise may appear or there may be momentary pauses in the sound.

### **SOUND MODE**

[12BIT]: Enables video recording of stereo sound on four separate channels, and is recommended for use when performing Audio Dubbing. (Equivalent to the 32 kHz mode of previous models)

16BIT: Enables video recording of stereo sound on two separate channels. (Equivalent to the 48 kHz mode of previous models)

### ZOOM

25X: When set to "25X" while using digital zoom, the zoom magnification will reset to 25X since digital zoom will be disengaged.

[100X]: Allows you to use the Digital Zoom. By digitally processing and magnifying images, zooming is possible from 25X (the optical zoom limit), to a maximum of 100X digital magnification.

800X: Allows you to use the Digital Zoom. By digitally processing and magnifying images. zooming is possible from 25X (the optical zoom limit), to a maximum of 800X digital magnification.

### **SNAP SHOT**

[FULL]: Snapshot mode with no frame

**NEGA**: Nega mode PIN-UP: Pin-Up mode

FRAME: Snapshot mode with frame









[FULL]

NEGA

PIN-UP

For details on the procedure, refer to "Snapshot (For Video Recording)" (pg. 29).

### **GAIN UP**

**OFF**: Allows you to shoot dark scenes with no picture brightness adjustment.

[AGC]: The overall appearance may be grainy, but the image is bright.

**AUTO ★** A: The shutter speed is automatically adjusted. Shooting a subject in low or poor lighting at slow shutter speed provides a brighter image than in the AGC mode, but the subject's movements are not smooth or natural. The overall appearance may be grainy. While the shutter speed is being automatically adjusted. "⇒\:\A" is displayed.

### MANUAL

The "MANUAL" settings are effective only when the Power Switch is set to "M".

[] = Factory-preset

### DIS

OFF: Disables the function.

[ON (4) ]: To compensate for unstable images caused by camera-shake, particularly at high magnification.

#### **NOTES:**

- Accurate stabilization may not be possible if hand shake is excessive, or depending on the shooting condition.
- The "(\*)" indicator blinks or goes out if the Stabilizer cannot be used.
- Switch off this mode when recording with the camcorder on a tripod.

#### **5S**

[OFF]: Disables 5-Second Recording.
5S: Enables 5-Second Recording. ( pg. 28)
Anim.: Allows you to record a few frames only.
By using an inanimate object and changing its position between shots, you can record the subject as though it is moving.

### **TELE MACRO**

[OFF]: Disables the function.

ON: When the distance to the subject is less than 1 m (3.3 ft), set "TELE MACRO" to "ON". You can shoot a subject as large as possible at a distance of approx. 40 cm (1.4 ft).

#### NOTE:

Depending on the zoom position, the lens may go out of focus.

### WIDE MODE

[OFF]: Records with no change in the screen ratio. For playback on a TV with a normal screen ratio.

CINEMA: Inserts black bands at the top and bottom of the screen. The indicator appears. During playback on wide-screen TVs, the black bands at the top and bottom of the screen are cut and the screen ratio becomes 16:9. When using this mode, refer to your wide-screen TV's instruction manual. During playback/recording on 4:3 TVs/LCD monitor/viewfinder, black bands are inserted at the top and bottom of the screen and the image appears like a letter boxed 16:9 movie.

SQUEEZE

: For playback on TVs with an aspect ratio of 16:9. Naturally expands the image to fit the screen without distortion. The indicator appears. When using this mode, refer to your wide-screen TV's instruction manual. During playback/recording on 4:3 TVs/LCD monitor/viewfinder, the image is elongated vertically.

### WIND CUT

[OFF]: Disengages the function.

ON ≋: Helps cut down on noise created by wind. The " ≋ " indicator appears. The quality of the sound will change. This is normal.

#### SYSTEM

The "SYSTEM" functions which are set when the Power Switch is set to "M" are also applied when the Power Switch is set to "PLAY".

[ ] = Factory-preset

#### BEEP

OFF: Even though not heard while shooting. shutter sound is recorded on the tape.

BEEP: The beep sounds when the power is turned on or off, and at the beginning and end of recording. It also activates the shutter sound effect. (pg. 29)

[MELODY]: Instead of a beep, a melody sounds when any operation is performed. It also activates the shutter sound effect. (F pg. 29)

### REMOTE

OFF: Disables the remote control operations. [ON]: Enables the remote control operations. It is recommended that this function be set to "OFF" to prevent improper operation.

#### DEMO MODE

OFF: Automatic demonstration will not take place.

**ION1**: Demonstrates certain functions such as Program AE with special effects, etc., and can be used to confirm how these functions operate. Demonstration starts in the following cases:

- When the Menu Screen is closed after "DEMO. MODE" is turned "ON".
- With "DEMO MODE" set to "ON", if there is no operation for about 3 minutes after the Power Switch is set to "A" or "M".
- Performing any operation during the demonstration stops the demonstration temporarily. If no operation is performed for more than 3 minutes after that, the demonstration will resume.

#### **NOTES:**

- If a cassette is in the camcorder, the demonstration cannot be turned on.
- "DEMO MODE" remains "ON" even if the camcorder power is turned off.
- If "DEMO MODE" remains "ON", some functions will not be available. After viewing demo, set to "OFF"

### **PRIORITY**

[LCD]: The image is displayed on the LCD monitor when the viewfinder is pulled out while the LCD monitor is opened.

FINDER: The image is displayed in the viewfinder when the viewfinder is pulled out while the LCD monitor is opened.

### **CAM RESET**

**EXECUTE**: Resets all settings to the factorypreset.

[RETURN]: Does not reset all settings to the factory-preset.

### CAMERA DISPLAY

- The "OI" (CAMERA DISPLAY) settings are effective even when the Power Switch is set to "IA". However, the menu settings can be changed only when the Power Switch is set to "IM".
- The "O" (CAMERA DISPLAY) settings except "BRIGHT" and "LANGUAGE" are effective only for shooting.
- [] = Factory-preset

### **BRIGHT**

g pg. 15, "Brightness Adjustment Of The Display"

### **ON SCREEN**

LCD: Keeps the camcorder's display (except the date, time and time code) from appearing on the connected TV screen.

[LCD/TV]: Makes the camcorder's display appear on screen when the camcorder is connected to a TV.

### DATE/TIME

**OFF**: The date/time does not appear. **[AUTO]**: Displays the date/time for approx. 5 seconds when the Power Switch is set from "OFF" to "A" or "M".

ON: The date/time is always displayed.

### **TIME CODE**

[OFF]: Time code is not displayed.

ON: Time code is displayed on the camcorder and on the connected TV. Frame numbers are not displayed during recording. ( pg. 19)

#### LANGUAGE

[ENGLISH] / ESPAÑOL

The language setting can be changed. (Fig. 14)

#### CLOCK ADJ.

pg. 14, "Date/Time Settings"

### Playback Menus

### ■ VIDEO

[] = Factory-preset

#### SOUND MODE and NARRATION

During tape playback, the camcorder detects the sound mode in which the recording was made, and plays the sound back. Select the type of sound to accompany your playback picture. According to the menu access explanation on page 22, select "SOUND MODE" or "NARRATION" from the Menu Screen and set it to the desired parameter.

### **SOUND MODE**

[STEREO ▶ ]: Sound is output on both "L" and "R" channels in stereo.

**SOUND L** D: Sound from the "L" channel is output.

SOUND R ଐ: Sound from the "R" channel is output.

### NARRATION

**[OFF]**: Original sound is output on both "L" and "R" channels in stereo.

ON: Dubbed sound is output on both "L" and "R" channels in stereo.

MIX: Original and dubbed sounds are combined and output in stereo on both "L" and "R" channels.

### REC MODE [SP] / LP

Allows you to set the video recording mode (SP or LP) depending on your preference. It is recommended you use "REC MODE" in VIDEO Menu when using this camcorder as a recorder during dubbing. ( pg. 35, 36)

### **BLANK SRCH**

g pg. 20, "Blank Search"

#### SYSTEM

Each setting is linked with "A SYSTEM", which appears when the Power Switch is set to "M". (F pg. 22)

 The parameters are the same as in the description on page 25.

### VIDEO DISPLAY

The "O" (VIDEO DISPLAY) settings are effective only for video playback except "BRIGHT" and "LANGUAGE".

• The parameters (except "OFF" in ON SCREEN settings) are the same as in the description (CAMERA DISPLAY) on page 26. [ ] = Factory-preset

### **BRIGHT**

pg. 15, "Brightness Adjustment Of The Display"

### ON SCREEN OFF / [LCD] / LCD/TV

When set to "OFF", the camcorder's display disappears.

#### [OFF] / AUTO / ON DATE/TIME

When set to "AUTO", the date/time are displayed in the following cases:

- When playback starts. The camcorder displays the date/time when scenes are recorded.
- When the date is changed during playback.

#### **TIME CODE** [OFF] / ON

r pg. 19, "Time Code"

### LANGUAGE

### [ENGLISH] / ESPAÑOL

The language setting can be changed. (c pg. 14)

### 5-Second Recording

Record a vacation or an important event in 5second clips to keep the action moving. This function is available only for video recording.

- I Set "5S" to "5S". (☞ pg. 24)
- The "5S" indicator appears.
- **2** Press the Recording Start/Stop Button to start recording, and after 5 seconds the camcorder enters Record-Standby mode automatically.
- Even if you press the Recording Start/Stop Button again within 5 seconds after recording starts, Record-Standby mode is not engaged.
- 3 To exit the 5S mode, select "OFF" in step 1.

### To take a snapshot in the 5-second recording mode

Instead of pressing the Recording Start/Stop Button in step 2, select the desired Snapshot mode in CAMERA Menu (pg. 23), then press SNAPSHOT. The camcorder records a 5second still. When "5S" is set to "Anim.", this function is not available.

#### NOTE:

When "5S" is set to "Anim.", the 5-Second Recording mode is not available. Animation recording of a few frames only is taken instead.

### Night-Alive

Makes dark subjects or areas even brighter than they would be under good natural lighting. Although the recorded image is not grainy, it may look as if it is strobing due to the slow shutter speed.

- Set the Power Switch to "M".
- 2 Press NIGHT so that the Night-Alive indicator "appears."
- The shutter speed is automatically adjusted to provide up to 30 times sensitivity.
- "A" appears beside "oo" while the shutter speed is being automatically adjusted.

### To deactivate Night-Alive

Press NIGHT again so that the Night-Alive indicator disappears.

- · During Night-Alive, the following functions or settings cannot be activated and its indicator blinks or goes out:
  - · Some modes of "Program AE With Special Effects" (pg. 34).
  - "GAIN UP" in CAMERA Menu (pg. 23).
  - "DIS" in MANUAL Menu (pg. 24).
- During Night-Alive, it may be difficult to bring the camcorder into focus. To prevent this, use of a tripod is recommended.

### Snapshot (For Video Recording)

This feature lets you record still images that look like photographs onto a tape.

- Set the Power Switch to "M".
- 2 Set "SNAP SHOT" to the desired mode. (F pg. 22, 23)
- 3 Press SNAPSHOT.
- There is the sound effect of a shutter closing.
- The "PHOTO" indication appears and a still image will be recorded for approx. 6 seconds, then the camcorder re-enters the Record-Standby mode.
- You can perform Snapshot also during recording. A still image will be recorded for approx. 6 seconds, then the normal recording resumes.
- Regardless of the Power Switch position ("A" or "M"), Snapshot recording takes place using the selected Snapshot mode.

### Motor Drive Mode

Keeping SNAPSHOT pressed in step 3 provides an effect similar to serial photography. (Interval between still images: approx. 1 second)

### Manual Focus


The camcorder's Full Range AF system offers continuous shooting ability from close-up (as close as approx. 5 cm (2") to the subject) to infinity.

However, correct focus may not be obtained depending on the shooting condition. In this case, use the manual focus mode.

Set the Power Switch to "M".

2 Press FOCUS. The manual focus indicator appears.

3 Press + or - to focus on a subject.





indicator

cannot be adjusted any further or closer. " A " or "A" will blink.

### 4 Press MENU. Focus adjustment is complete.

#### To reset to Auto Focus

Press FOCUS twice or set the Power Switch to "A".

### Manual focus is recommended in situations listed below.

- When two subjects overlap in the same scene.
- When illumination is low.\*
- When the subject has no contrast (difference in brightness and darkness), such as a flat, onecolor wall, or a clear, blue sky.\*
- When a dark object is barely visible in the LCD monitor or the viewfinder.\*
- When the scene contains minute patterns or identical patterns that are regularly repeated.
- When the scene is affected by sunbeams or light reflecting off the surface of a body of water.
- When shooting a scene with a high-contrast background.
- \* The following low-contrast warnings appear blinking: **△**, **◄**, **▶** and **≗**.

### **Exposure Control**

Manual exposure control is recommended in the following situations:

- When shooting using reverse lighting or when the background is too bright.
- When shooting on a reflective natural background such as at the beach or when skiing.
- When the background is overly dark or the subject is bright.
- Set the Power Switch to "M".
- 2 Set " to "MANUAL". ( pg. 22)
- The exposure control indicator appears.
- **3** To brighten the image, press +. To darken the image, press -. (maximum ±6)
- +3 exposure has the same effect as the backlight compensation. ( pp. 31)
- **4** Press **MENU**. Exposure adjustment is complete.

To return to automatic exposure control Select "AUTO" in step **2**. Or, set the Power Switch to "A".

### **NOTES:**

- You cannot use the manual exposure control at the same time when "☐" is set to "SPOTLIGHT" or "SNOW" (☐ pg. 34), or with the backlight compensation.
- If the adjustment does not cause any visible change in brightness, set "GAIN UP" to "AUTO". ( pg. 22, 23)

### Iris Lock

Like the pupil of the human eye, the iris contracts in well-lit environments to keep too much light from entering, and dilates in dim environments to allow in more light.

Use this function in the following situations:

- When shooting a moving subject.
- When the distance to the subject changes (so its size in the LCD monitor or the viewfinder changes), such as when the subject is backing away.
- When shooting on a reflective natural background such as at the beach or when skiing.
- When shooting objects under a spotlight.
- When zooming.
- Set the Power Switch to "M".
- **2** Set "**□**" to "MANUAL". (☞ pg. 22)
- The exposure control indicator appears.
- **3** Adjust zoom so that the subject fills the LCD monitor or the viewfinder, then press and hold **MENU** for over 2 seconds. The exposure control indicator and the "**1**" indication appear.
- **4** Press **MENU**. The "■" indication changes to "□" and the iris is locked.

To return to automatic iris control Select "AUTO" in step **2**. Or, set the Power Switch to "**A**".

 The exposure control indicator and "L" disappear.

To lock the exposure control and the iris
After step 2, adjust the exposure by pressing +
or –. Then lock the iris in steps 3 and 4. For

automatic locking, select "AUTO" in step **2**. The exposure control and the iris become automatic.

### **Backlight Compensation**

Backlight compensation brightens the subject auickly.

With simple operation, backlight compensation feature brightens the dark subject portion by increasing the exposure.

Set the Power Switch to "M".

2 Press BACK LIGHT so that the Backlight Compensation indicator " appears.

To cancel Backlight Compensation Press BACK LIGHT twice so that the "
"" indicator disappears.

### NOTE:

Using Backlight Compensation may cause the light around the subject to become too bright and the subject to become white.

### Spot Exposure Control

Selection of a spot metering area enables more precise exposure compensation. You can select one of the three metering areas on the LCD monitor/viewfinder.

Set the Power Switch to "M".

2 Press BACK LIGHT twice so that the Spot Exposure Control indicator " appears.

- A spot metering area frame appears at the centre of the LCD monitor/viewfinder.
- 3 Press + or to select the desired spot metering area frame.

### 4 Press MENU.

- Spot Exposure Control is engaged.
- Exposure is adjusted to make the brightness of the selected area most appropriate.

#### To lock the iris

After step 3, press and hold MENU over 2 seconds. The "L" indication appears and the iris is locked.

### To cancel Spot Exposure Control

Press BACK LIGHT once so that the " ]" indicator disappears.

- You cannot use the Spot Exposure Control at the same time with following functions.
  - "SQUEEZE" in "WIDE MODE" (pg. 24)
  - "STROBE" in "PROGRAM AE" (pg. 34)
  - Digital Zoom (pg. 18)
  - Manual Exposure Control
- Depending on the shooting location and condition, optimum result may not be attained.

# White Balance Adjustment

The white balance refers to the correctness of color reproduction under various lighting. If the white balance is correct, all other colors will be accurately reproduced.

The white balance is usually adjusted automatically. However, more advanced camcorder operators control this function manually to achieve a more professional color/ tint reproduction.

#### To change the setting

Set "™" to the desired mode. (☐ pg. 22)

The selected mode indicator except "AUTO"


[AUTO]: White balance is adjusted automatically.

- MWB: Adjust the white balance manually when shooting under various types of lighting. ( "Manual White Balance Adjustment")
  - FINE: Outdoors on a sunny day.
- CLOUD: Outdoors on a cloudy day.
- **HALOGEN**: A video light or similar type of lighting is used.
- [] = Factory-preset

To return to automatic white balance Set "Set "AUTO". ( pg. 22) Or. set the Power Switch to "A".

### Manual White Balance Adjustment

Adjust the white balance manually when shooting under various types of lighting.





White paper

- 2 Hold a sheet of plain white paper in front of the subject. Adjust zoom or position yourself so that the white paper fills the screen.
- 3 Select "MWB" in "™ W.BALANCE" menu (pg pg. 22), then press and hold **MENU** until \bigsilon begins blinking.
- When the setting is completed, stops blinking.
- 4 Press MENU twice. The Menu Screen closes and the Manual White Balance indicator M is displayed.

- In step 2, it may be difficult to focus on the white paper. In such a case, adjust focus manually. (car pg. 29)
- A subject can be shot under various types of lighting conditions indoors (natural, fluorescent, candlelight, etc.). Because the color temperature is different depending on the light source, the subject tint will differ depending on the white balance settings. Use this function for a more
- Once you adjust white balance manually, the setting is retained even if the power is turned off or the battery removed.

### Wipe Or Fader Effects

These effects let you make pro-style scene transitions. Use them to spice up the transition from one scene to the next.

Wipe or Fader works when video recording is started or stopped.

■ Set the Power Switch to "M".

2 Set "s" to the desired mode. (F pg. 22)

- The WIPE/FADER menu disappears and the effect is reserved
- The selected effect indicator appears.
- 3 Press the Recording Start/Stop Button to activate the Fade-in/out or Wipe-in/out.

### To deactivate the selected effect Select "OFF" in step 2. The effect indicator disappears.

#### NOTES:

- You can extend the length of a Wipe or Fader by pressing and holding the Recording Start/Stop
- Some Wipe/Fader Effects cannot be used with certain modes of Program AE with special effects. (pg. 34) In this case, the selected indicator blinks or goes out.

### **■** WIPE/FADER

OFF: Disables the function. (Factory-preset)

WH FADER-WHITE: Fade in or out with a white screen.

|BK| FADER-BLACK: Fade in or out with a black screen.

**BW** FADER-B.W: Fade in to a color screen from a black and white screen, or fade out from color to black and white.

WIPE-CORNER: Wipe in on a black screen from the upper right to the lower left corner, or wipe out from lower left to upper right, leaving a black screen.

■ WIPE-WINDOW: The scene starts in the centre of a black screen and wipes in toward the corners, or comes in from the corners, gradually wiping out to the centre.

WIPE-SLIDE: Wipe in from right to left, or wipe out from left to right.

WIPE-DOOR: Wipe in as the two halves of a black screen open to the left and right, revealing the scene, or wipe out and the black screen reappears from left and right to cover the scene.

▲ WIPE-SCROLL: The scene wipes in from the bottom to the top of a black screen, or wipes out from top to bottom, leaving a black screen.

WIPE-SHUTTER: Wipe in from the centre of a black screen toward the top and bottom, or wipe out from the top and bottom toward the centre leaving a black screen.

### **Program AE With Special Effects**

- Set the Power Switch to "M".
- **2** Set "" to the desired mode. (🖙 pg. 22)
- The PROGRAM AE menu disappears and the selected effect is activated
- The selected effect indicator appears.

To deactivate the selected effect Select "OFF" in step 2. The effect indicator disappears.

#### **NOTES:**

- Program AE with special effects can be changed during recording or during Record-Standby.
- Some modes of Program AE with special effects cannot be used during Night-Alive.
- When a subject is too bright or reflective, a vertical streak may appear (smear phenomenon). Smear phenomenon tends to occur when "SPORTS" or any mode of "SHUTTER 1/250 - 1/4000" is selected.
- Some modes of Program AE with special effects cannot be used with certain Wipe/Fader effects. (pg. 33) In this case, the selected indicator blinks or goes out.

### PROGRAM AE

OFF: Disables the function. (Factory-preset) 1/60 SHUTTER 1/60: The shutter speed is fixed at 1/60th of a second. Black bands that usually appear when shooting a TV screen become narrower.

1/100 SHUTTER 1/100: The shutter speed is fixed at 1/100th of a second. The flickering that occurs when shooting under a fluorescent light or mercury-vapour lamp is reduced.

### SHUTTER 1/250/ SHUTTER 1/500/ SHUTTER 1/1000/ SHUTTER 1/2000/

SHUTTER 1/4000: These settings allow fastmoving images to be captured one frame at a time, for vivid, stable slow-motion playback by fixing shutter speed variables. Use these settings when an automatic adjustment does not work well, using SPORTS mode. The faster the shutter speed, the darker the picture becomes. Use the shutter function under good lighting conditions.

### SPORTS

(Variable Shutter Speed: 1/250 - 1/4000):

This setting allows fast-moving images to be captured one frame at a time, for vivid, stable slow-motion playback. The faster the shutter speed, the darker the picture becomes. Use the shutter function under good lighting conditions.

SNOW: Compensates for subjects that may otherwise appear too dark when shooting in extremely bright surroundings such as in the snow.

■ SPOTLIGHT: Compensates for subjects that may otherwise appear too bright when shooting under extremely strong direct lighting such as spotlights.

**△**\* TWILIGHT: Makes evening scenes look more natural. White Balance ( pg. 32) is automatically set to "...", but can be changed to your desired setting. When Twilight is chosen, the camcorder automatically adjusts the focus from approx. 10 m (32 ft) to infinity. From less than 10 m, adjust the focus manually.

SEPIA: Recorded scenes have a brownish tint like old photos. Combine this with the Cinema mode ( pg. 24. "WIDE MODE" ) for a classic look.


B/W MONOTONE: Like classic black and white films, your footage is shot in B/W. Used together with the Cinema mode (pg. 24, "WIDE MODE"), it enhances the "classic film" effect.

CLASSIC FILM: Gives recorded scenes a strobe effect.

STROBE: Your recording looks like a series of consecutive snapshots.

MIRROR: Creates a mirror image on the right half of the screen, juxtaposed to the normal image on the other half.

### **Dubbing To A VCR**




- 1 Yellow to VIDEO IN
- 2 Red to AUDIO R IN
- White to AUDIO L IN

- I Following the illustrations, connect the camcorder and the VCR's input connectors.
- 2 Start playback on the camcorder. (pg. 20)
- 3 At the point you want to start dubbing, start recording on the VCR. (Refer to the VCR's instruction manual.)
- 4 To stop dubbing, stop recording on the VCR, then stop playback on the camcorder.

- It is recommended to use the AC Adapter as the power supply instead of the battery pack. (car pg. 13)
- To choose whether or not the following displays appear on the connected TV
  - Date/time Set "DATE/TIME" to "AUTO", "ON" or "OFF". (pg. 22, 27)
  - Time code Set "TIME CODE" to "OFF" or "ON". (pg. 22, 27)
  - Indications other than date/time and time code Set "ON SCREEN" to "OFF", "LCD" or "LCD/ TV". (F pg. 22, 27)

### Dubbing To Or From A Video Unit Equipped With A DV Connector (Digital Dubbing)

It is also possible to copy recorded scenes from the camcorder onto another video unit equipped with a DV connector. Since a digital signal is sent, there is little if any image or sound deterioration.



Video unit equipped with DV connector

### To use this camcorder as a player

- Make sure all units are turned off.
- **2** Connect this camcorder to a video unit equipped with a DV input connector using a DV cable as shown in the illustration.
- 3 Start playback on the camcorder. ( pg. 20)
- **4** At the point you want to start dubbing, start recording on the video unit. (Refer to the video unit's instruction manual.)
- **5** To stop dubbing, stop recording on the video unit, then stop playback on this camcorder.

#### NOTES:

- It is recommended to use the AC Adapter as the power supply instead of the battery pack.
   pg. 13)
- If a blank portion or disturbed image is played back on the player during dubbing, the dubbing may stop so that an unusual image is not dubbed.
- Even though the DV cable is connected correctly, sometimes the image may not appear in step 4. If this occurs, turn off the power and make connections again.
- When using a DV cable, be sure to use the optional JVC VC-VDV204U DV cable.

#### To use this camcorder as a recorder

- Make sure all units are turned off.
- **2** Connect this camcorder to a video unit equipped with a DV output connector using a DV cable as shown in the illustration.
- **3** Set the camcorder's Power Switch to "PLAY".
- 4 Set "REC MODE" to "SP" or "LP". (Fig. 26)
- **5** Press the Recording Start/Stop Button to engage the Record-Pause mode.
- The " DV IN " indication appears on the screen.
- **6** Start playback on the player.
- At the point you want to start dubbing, press the Recording Start/Stop Button to start dubbing. The thickness indication rotates.
- 8 Press the Recording Start/Stop Button again to stop dubbing. The \$\indth\ indication stops rotating.
- **9** Press to return to the normal playback mode.

#### NOTE:

Digital Dubbing is performed in the sound mode recorded on the original tape, regardless of the current "SOUND MODE" setting. ( $\[murphi]$  pg. 23)

### Connection To A Personal Computer

It is also possible to transfer still/moving images to a PC with a DV connector by using the software equipped with the PC or commercially available software.


If you are using a Windows® XP, you can use Windows® Messenger to conduct video conferences over the Internet, using a camcorder. For details, refer to the help for the Windows® Messenger.

#### **NOTES:**

- It is recommended to use the AC Adapter as the power supply instead of the battery pack. (car pq. 13)
- . When using a DV cable, be sure to use the optional JVC VC-VDV206U or VC-VDV204U DV cable depending on the type of DV connector (4 or 6 pins) on the PC.
- The date/time information cannot be captured into the PC.
- Refer to the instruction manuals of the PC and Software.
- The still images can also be transferred to a PC with a DV connector-equipped capture board.
- The system may not work properly depending on the PC or capture board you are using.

When connecting the camcorder to a PC using a DV cable, make sure to follow the procedure below. Connecting the cable incorrectly may cause malfunctions to the camcorder and/or the PC.

- Connect the DV cable first to the PC, and then to the camcorder.
- Connect the DV cable (plugs) correctly according to the shape of the DV connector.



If, after following the steps in the chart below, the problem still exists, please consult your nearest JVC dealer.

The camcorder is a microcomputer-controlled device. External noise and interference (from a TV, a radio, etc.) might prevent it from functioning properly. In such cases, first disconnect its power supply unit (battery pack, AC Adapter, etc.) and wait a few minutes; and then re-connect it and proceed as usual from the beginning.

#### **Power**

#### No power is supplied.

- The power is not connected properly.
- → Connect the AC Adapter securely. ( pg. 13)
- The battery pack is not attached firmly.
- → Detach the battery pack once again and re-attach it firmly. (☞ pg. 11)
- · The battery is dead.
- → Replace the dead battery with a fully charged one. (☐ pg. 11)

#### Video Recording

#### Recording cannot be performed.

- The tape's erase protection tab is set to "SAVE".
- → Set the tape's erase protection tab to "REC".
  (□ pg. 16)
- "TAPE END" appears.
- → Replace with new cassette. (☐ pg. 16)
- The cassette holder cover is open.
- →Close the cassette holder cover.

# When shooting a subject illuminated by bright light, vertical lines appear.

This is not a malfunction.

When the screen is under direct sunlight during shooting, the screen becomes red or black for an instant.

This is not a malfunction.

# During recording, the date/ time does not appear.

- "DATE/TIME" is set to "OFF".
- → Set "DATE/TIME" to "ON". (127 pg. 22, 26)

# The LCD monitor or viewfinder indications blink.

- Certain Wipe/Fader effects, certain modes of Program AE with special effects, "DIS" and other functions that cannot be used together are selected at the same time.
- → Re-read the sections covering Wipe/Fader effects, Program AE with special effects and "DIS". (□ pg. 22, 24, 33, 34)

#### Digital Zoom does not work.

- 25X optical zoom is selected.
- → Set "ZOOM" to "100X" or "800X". (127 pg. 23)

#### Video Playback

#### The tape is moving, but there is no picture.

- Your TV has AV input terminals, but is not set to its VIDEO mode.
- → Set the TV to the mode or channel appropriate for video playback. (☑ pg. 21)
- The cassette holder cover is open.
- → Close the cassette holder cover. ( pg. 16)

#### Blocks of noise appear during playback, or there is no playback picture and the screen becomes blue.

→ Clean the video heads with an optional cleaning cassette. (□ pg. 44)

#### Advanced features

#### The focus does not adjust automatically.

- · Focus is set to the Manual mode.
- → Set Focus to the Auto mode. (pg. 29)
- The lens is dirty or covered with condensation.
- → Clean the lens and check the focus again. (□ pg. 42)

# In the 5-Second mode, recording ends before 5 seconds have elapsed.

- The 5-Second mode is set to "Anim." in MANUAL Menu.
- → Set "5S" to "5S" in MANUAL Menu. (☐ pg. 22, 28)

#### Snapshot mode cannot be used.

- The Squeeze mode (SQUEEZE) is selected.
- → Disengage the Squeeze (SQUEEZE) mode. (pg. 22, 24)

#### The color of Snapshot looks strange.

- The light source or the subject does not include white. Or there are various different light sources behind the subject.
- → Find a white subject and compose your shot so that it also appears in the frame. (pg. 29)

#### The image taken using Snapshot is too dark.

- Shooting was performed under backlit conditions.
- →Press BACK LIGHT. (pg. 31)

#### The image taken using Snapshot is too bright.

- The subject is too bright.
- → Set "" to "SPOTLIGHT". (pg. 34)

#### White Balance cannot be activated.

- The Sepia (SEPIA) or Monotone (MONOTONE) mode is activated.
- → Disengage the Sepia (SEPIA) or Monotone (MONOTONE) mode before setting White Balance. (pg. 34)

#### The Black & White Fader does not work.

- The Sepia (SEPIA) or Monotone (MONOTONE) mode is activated.
- → Disengage the Sepia (SEPIA) and Monotone (MONOTONE). (pg. 34)

#### The image looks like the shutter speed is too slow.

- When shooting in the dark, the unit becomes highly sensitive to light when "GAIN UP" is set to "AUTO".
- → If you want the lighting to look more natural, set "GAIN UP" to "AGC" or "OFF". (127 pg. 22, 23)

#### Other problems

#### The POWER/CHARGE lamp on the camcorder does not light during charging.

- Charging is difficult in places subject to extremely high/low temperatures.
- → To protect the battery, it is recommended to charge it in places with a temperature of 10°C to 35°C (50°F to 90°F). (pg. 43)
- The battery pack is not attached firmly.
- → Detach the battery pack once again and re-attach it firmly. (pg. 11)

#### "SET DATE/TIME!" appears.

- The date/time is not set.
- → Set the date/time. (pg. 14)
- The built-in clock battery has run out and the previously set date/time has been erased.
- → Consult your nearest JVC dealer for replacement.

#### When the image is printed from the printer, a black bar appears at the bottom of the screen.

- This is not a malfunction.
- → By recording with "DIS" activated (pg. 22, 24) this can be avoided.

#### When the camcorder is connected via the DV connector, the camcorder does not operate.

- The DV cable was plugged/unplugged with power turned on.
- → Turn the camcorder's power off and on again, then operate it.

#### Images on the LCD monitor appear dark or whitish.

- In places subject to low temperature, images become dark due to the characteristics of the LCD monitor. This is not a malfunction.
- → Adjust the brightness and angle of the LCD monitor. (127 pg. 15. 18)
- When the LCD monitor's fluorescent light reaches the end of its service life, images on the LCD monitor become dark.
- → Consult your nearest JVC dealer.

#### Colored bright spots appear all over the LCD monitor or the viewfinder.

• The LCD monitor and the viewfinder are made with high-precision technology. However, black spots or bright spots of light (red, green or blue) may appear constantly on the LCD monitor or the viewfinder. These spots are not recorded on the tape. This is not due to any defect of the unit. (Effective dots: more than 99.99 %)

#### The cassette will not load properly.

- The battery's charge is low.
- →Install a fully charged battery. ( pg. 11)

# Picture does not appear on the LCD

- The viewfinder is pulled out and "PRIORITY" is set to "FINDER".
- → Push the viewfinder back in or set "PRIORITY" to "LCD". (☐ pg. 18, 22, 25)
- The LCD monitor's brightness setting is too dark.
- → Adjust the brightness of the LCD monitor. (☐ pg. 15)
- → If the monitor is tilted upward 180 degrees, open the monitor fully. (□ pg. 18)

#### An error indication (01 - 04 or 06) appears.

- A malfunction of some kind has occurred. In this case the camcorder's functions become unusable.
- → pg. 41.

monitor.

#### **Warning Indications**

#### B

Displays the battery remaining power.

#### Remaining power level

## High



As the battery power comes close to nil, the battery remaining power indicator blinks. When the battery power is exhausted, power turns off automatically.

#### 9

Appears when no tape is loaded. (Fig. 16)

#### **CHECK TAPE'S ERASE PROTECTION TAB**

Appears when the erase protection tab is set to "SAVE" while the Power Switch is set to "A" or "M". ( pg. 13)

#### **⊗** USE CLEANING CASSETTE

Appears if dirt is detected on the heads during recording. Use an optional cleaning cassette. ( pg. 44)

# CONDENSATION, OPERATION PAUSED PLEASE WAIT

Appears if condensation occurs. When this indication is displayed, wait more than 1 hour until condensation disappears.

#### TAPE!

Appears if a tape is not loaded when the Recording Start/Stop Button or **SNAPSHOT** Button is pressed while the Power Switch is set to "A" or "M".

#### **TAPE END**

Appears when the tape ends during recording or playback.

#### SET DATE/TIME!

- Appears when the date/time is not set.
   (pg. 14)
- The built-in clock battery has run out and the previously set date/time has been erased.
   Consult your nearest JVC dealer for replacement.

#### **LENS CAP**

Appears for 5 seconds after power is turned on if the lens cap is attached or when it is dark.

#### HDV 🚥

Appears when pictures recorded in the HDV format are detected. The pictures in the HDV format cannot be played back with this camcorder.

#### **UNIT IN SAFEGUARD MODE** REMOVE AND REATTACH BATTERY

The error indications (01, 02 or 06) show what type of malfunction has occurred. When an error indication appears, the camcorder turns off automatically. Remove the power supply (battery, etc.) and wait a few minutes for the indication to clear. When it does, you can resume using the camcorder. If the indication remains, consult your nearest JVC dealer.

#### **UNIT IN SAFEGUARD MODE EJECT AND REINSERT TAPE**

The error indications (03 or 04) show what type of malfunction has occurred. When an error indication appears, the camcorder turns off automatically. Eject the cassette once and reinsert it, then check if the indication clears. When it does, you can resume using the camcorder. If the indication remains, consult your nearest JVC dealer.

## **Cleaning The Camcorder**

Before cleaning, turn off the camcorder and remove the battery pack and AC Adapter.

#### To clean the exterior

Wipe gently with a soft cloth. Put the cloth in diluted mild soap and wring it well to wipe off heavy dirt. Then wipe again with a dry cloth.

#### To clean the LCD monitor

Wipe gently with a soft cloth. Be careful not to damage the monitor. Close the LCD monitor.

#### To clean the lens

Blow it with a blower brush, then wipe gently with lens cleaning paper.

#### **NOTES:**

- Avoid using strong cleaning agents such as benzine or alcohol.
- Cleaning should be done only after the battery pack has been removed or other power units have been disconnected.
- Mould may form if the lens is left dirty.
- When using a cleaner or chemically treated cloth refer to the cautions of each product.
- To clean the viewfinder, please consult your nearest JVC dealer.

#### **AC Adapter**

#### When using the AC Adapter in areas other than the USA

The provided AC Adapter features automatic voltage selection in the AC range from 110 V to 240 V

#### USING HOUSEHOLD AC PLUG ADAPTER

In case of connecting the unit's power cord to an AC wall outlet other than American National Standard C73 series type use an AC plug adapter. called a "Siemens Plug", as shown.

For this AC plug adapter, consult your nearest JVC dealer.



#### **Battery Packs**

The supplied battery pack is a lithium-ion battery. Before using the supplied battery pack or an optional battery pack, be sure to read the following cautions:





#### To avoid hazards

- ... do not burn.
- ... do not short-circuit the terminals. When transporting, make sure the provided battery cap is attached to the battery. If the battery cap is misplaced, carry the battery in a plastic bag.
- ... do not modify or disassemble.
- ... do not expose the battery to temperatures exceeding 60°C (140°F), as this may cause the battery to overheat, explode or catch fire.
- ... use only specified chargers.

## To prevent damage and prolong service

- ... do not subject to unnecessary shock.
- ... charge in an environment where temperatures are within the tolerances shown in the chart below. This is a chemical reaction type battery cooler temperatures impede chemical reaction, while warmer temperatures can prevent complete charging.
- ... store in a cool, dry place. Extended exposure to high temperatures will increase natural discharge and shorten service life.
- ...fully charge and then fully discharge the battery every 6 months when storing the battery pack over a long period time.

... remove from charger or powered unit when not in use, as some machines use current even when switched off

#### The Benefits Of Lithium-Ion Batteries

Lithium-ion battery packs are small but have a large power capacity. However, when one is exposed to cold temperatures (below 10°C/ 50°F), its usage time becomes shorter and it may cease to function. If this happens, place the battery pack in your pocket or other warm, protected place for a short time, then reattach it to the camcorder.

#### NOTES:

• It is normal for the battery pack to be warm after charging, or after use.

Temperature Range Specifications Charging: 10°C to 35°C (50°F to 95°F) Operation: 0°C to 40°C (32°F to 104°F) Storage: -20°C to 50°C (-4°F to 122°F)

- The lower the temperature, the longer recharging
- Charging times are for a fully discharged battery pack.

#### Cassettes

To properly use and store your cassettes, be sure to read the following cautions:

#### During use

- ... make sure the cassette bears the Mini DV mark.
- ... be aware that recording onto prerecorded tapes automatically erases the previously recorded video and audio signals.
- ... make sure the cassette is positioned properly when inserting.
- ... do not load and unload the cassette repeatedly without allowing the tape to run at all. This slackens the tape and can result in damage.
- ... do not open the front tape cover. This exposes the tape to fingerprints and dust.

#### Store cassettes

- ... away from heaters or other heat sources.
- ... out of direct sunlight.
- ... where they won't be subject to unnecessary shock or vibration.
- ... where they won't be exposed to strong magnetic fields (such as those generated by motors, transformers or magnets).
- ... vertically, in their original cases.

#### **LCD Monitor**

## To prevent damage to the LCD monitor, DO NOT

- ... push it strongly or apply any shocks.
- ... place the camcorder with the LCD monitor on the bottom.

#### To prolong service life

- ... avoid rubbing it with coarse cloth.
- Be aware of the following phenomena for LCD monitor use. These are not malfunctions
- ... While using the camcorder, the surface around the LCD monitor and/or the back of the LCD monitor may heat up.
- ...If you leave power on for a long time, the surface around the LCD monitor becomes hot.

#### Main Unit

#### • For safety, DO NOT

- ... open the camcorder's chassis.
- ... disassemble or modify the unit.
- ... short-circuit the terminals of the battery pack. Keep it away from metallic objects when not in
- ...allow inflammables, water or metallic objects to enter the unit.
- ...remove the battery pack or disconnect the power supply while the power is on.
- ...leave the battery pack attached when the camcorder is not in use.

#### Avoid using the unit

- ...in places subject to excessive humidity or dust.
- ...in places subject to soot or steam such as near a cooking stove.
- ...in places subject to excessive shock or vibration. ...near a television set.
- ... near appliances generating strong magnetic or electric fields (speakers, broadcasting antennas, etc.).
- ...in places subject to extremely high (over 40°C or 104°F) or extremely low (under 0°C or 32°F) temperatures.

#### DO NOT leave the unit

- ...in places of over 50°C (122°F).
- ...in places where humidity is extremely low (below 35%) or extremely high (above 80%).
- ... in direct sunlight.
- ... in a closed car in summer.
- ... near a heater.

#### To protect the unit, DO NOT

- ... allow it to become wet.
- ...drop the unit or strike it against hard objects.
- ...subject it to shock or excessive vibration during transportation.
- ... keep the lens directed at extremely bright objects for long periods.
- ... expose the lens and viewfinder's lens to direct sunlight.
- ...carry it by holding the LCD monitor or the viewfinder.
  ...swing it excessively when using the hand strap or
- the grip.
  ...swing the soft camera case excessively when the
- ... swing the soft camera case excessively when the camcorder is inside it.

## Dirty heads can cause the following problems:





- ... No picture during playback.
- ... Blocks of noise appear during playback.
- ... During recording or playback, the Head Clog Warning indicator " appears.
- ... Recording cannot be performed properly. In such cases, use an optional cleaning cassette. Insert it and play back. If the cassette is used more than once consecutively, damage to the video heads may result. After the camcorder plays back for about 20 seconds, it stops automatically. Also refer to the cleaning cassette's instructions.
- If, after using the cleaning cassette, the problems still exist, consult your nearest JVC dealer.

Mechanical moving parts used to move the video heads and video tape tend to become dirty and worn out over time. In order to maintain a clear picture at all times, periodic check-ups are recommended after using the unit for about 1,000 hours. For periodic check-ups please consult your nearest JVC dealer.

#### About moisture condensation

- You have observed that pouring a cold liquid into a glass will cause drops of water to form on the glass' outer surface. This same phenomenon occurs on the head drum of a camcorder when it is moved from a cool place to a warm place, after heating a cold room. under extremely humid conditions or in a place directly subjected to the cool air from an air conditioner
- Moisture on the head drum can cause severe damage to the video tape, and can lead to internal damage to the camcorder itself.

#### Serious malfunctioning

If malfunctioning occurs, stop using the unit immediately and consult your local JVC dealer.

The camcorder is a microcomputer-controlled device. External noise and interference (from a TV, a radio, etc.) might prevent it from functioning properly. In such cases, first disconnect its power supply unit (battery pack. AC Adapter, etc.) and wait a few minutes and then re-connect it and proceed as usual from the beginning.

#### **Declaration of Conformity**

Model Number : GR-D250U : JVC Trade Name

Responsible party : JVC AMERICAS

CORP

Address : 1700 Valley Road Wavne, N. J. 07470

Telephone Number: 973-317-5000 This device complies with Part 15 of FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired

operation.

Changes or modifications not approved by JVC could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions. may cause harmful interference to radio communications. However, there is no quarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/ TV technician for help.

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

#### Camcorder

#### For General

Power supply

DC 11 V (Using AC Adapter)

DC 7.2 V (Using battery pack)

Power consumption

Approx. 3.2 W (LCD monitor off, viewfinder on)

Approx. 4.2 W (LCD monitor on, viewfinder off) Approx. 6.5 W (Maximum; when charging the

battery pack)

Dimensions (W x H x D)

56 mm x 94 mm x 112 mm (2-1/4" x 3/4" x 7/16") (with the LCD monitor closed and the viewfinder

pushed back in)

Weight

Approx. 430 g (0.95 lbs) (without battery, cassette and lens cap)

Approx. 510 g (1.1 lbs) (incl. battery, cassette and

lens cap)
Operating temperature

0°C to 40°C (32°F to 104°F)

Operating humidity

35% to 80%

Storage temperature

-20°C to 50°C (-4°F to 122°F)

Pickup 1/6" CCD

1/6 CCL

Lens

F 1.8, f = 2.2 mm to 55 mm, 25:1 power zoom lens **Filter diameter** 

riilei ulaili

ø27 mm

LCD monitor

2.5" diagonally measured, LCD panel/TFT active matrix system

Viewfinder

Electronic viewfinder with 0.16" color LCD

Speaker

Monaural

#### For Digital Video Camera

Format

DV format (SD mode)

Signal format NTSC standard

Recording/Playback format

Video: Digital component recording

Audio: PCM digital recording. 32 kHz 4-channel

(12-BIT), 48 kHz 2-channel (16-BIT)

Cassette

Mini DV cassette Tape speed

SP: 18.8 mm/s. LP: 12.5 mm/s

Maximum recording time (using 80 min.

cassette)

SP: 80 min., LP: 120 min.

#### For Connectors

ΑV

Video output: 1.0 V (p-p), 75  $\Omega$ , analogue

Audio output: 300 mV (rms), 1 k $\Omega$ , analogue, stereo

Input/output: 4-pin, IEEE1394 compliant

#### **AC Adapter**

Power requirement

AC 110 V to 240 V  $\sim$  , 50 Hz/60 Hz

Output

DC 11 V \_\_\_\_, 1 A

Specifications shown are for SP mode unless otherwise indicated. E & O.E. Design and specifications subject to change without notice.

Α	Т
AC Adapter 13	Tape Speed (REC MODE)23, 26
Animation24	Telephoto Setting
В	Time Code
Backlight Compensation31	Tripod Mounting
Battery Pack11, 13, 43	W
Beep	
Blank Search	Warning Indications
С	Wide Mode24
Changing The Menu Settings 22 – 27	Wipe Or Fader Effects33
Charging The Battery Pack	Z
Connection To A Personal Computer	Zooming 18, 23
D	
	E Cooond Departing 20
Data Battery	5-Second Recording28
Demonstration Mode	
Digital Image Stabilisation (DIS)24	
Dubbing	
E	
Exposure Control	
1	
Iris Lock	
L	
LCD Monitor and Viewfinder 15, 18	
Loading A Cassette	
M	
Manual Focus	
Motor Drive Mode	
N	
Night-Alive	
P	
Playback Sound	
Power-Linked Operation14	
Program AE With Special Effects34	
Q	
Quick Review	
R	
Recording Capacity	
Tape 17	
S	
Snapshot Mode23	
Sound Mode	
Speaker Volume	

Spot Exposure Control ......31

# JVC